

MANTEL BRACKET INSTRUCTIONS

Below are general instructions for mounting Summit Blue Mantel Brackets. These instructions are only intended to be general guidelines, and adaptations or adjustments may be required for your specific application. The installer is responsible to ensure compliance with all applicable building code requirements, and applicable building codes take precedence over any instructions in this document. All measurements are approximate.

1. Using a 3/16" concrete drill bit, carefully drill a hole in the rear center of the mantel bracket, approximately 1" from the top of the bracket.
2. Orient the flat metal mounting bracket so that the pre-drilled holes match the arrangement shown in the photo below. The 2 pre-drilled holes that are closer together should be positioned toward the top of the mantel bracket.
3. Using a 1/4" x 2 3/4" Tapcon (Phillips Flat-Head), carefully screw the Tapcon into the top hole as shown in the photo below. Do not overtighten.
4. Ensure that the flat metal mounting bracket is properly positioned and centered on the mantel bracket. Using the same drill bit from Step 1, carefully drill a hole in the mantel bracket in the location of the pre-drilled hole in the flat metal mounting bracket.
5. Using another 1/4" x 2 3/4" Tapcon (Phillips Flat-Head), carefully screw the Tapcon into the bottom hole as shown in the photo below. Do not overtighten.
6. Fasten the completed assembly to the wall using the pre-drilled holes for mounting. Ensure that the fasteners used are strong enough to support the weight of the mantel bracket and mantel, and also ensure that the fasteners are adequately secured into the wall structure.

